



NOTE) You have to install the driver for JIG-RS232COM-AF from the software CD before initiating the HD133 software (HD133Ctrl).